

VZ-DVMediaRig Professional Camera Support

Kit includes: (1) Adjustable Shoulder Arch (2) Handle Section (3) Belt (4) Spring Pod (5) Quick-release Plate (6) Tilt Lever (7) Accessory Mount (8) Swiveling counterweight (may differ from picture)



WARNING: NEVER POINT THE TIP OF THE SPRING POD AT YOUR FACE. ONLY LOOSEN THE CLAMPS WHEN THE SPRING POD IS ATTACHED TO THE LOADED DV MEDIA RIG. THE SPRING POD CAN POP OUT QUICKLY AND CAUSE INJURY IF THESE RULES ARE NOT FOLLOWED.

- 1) Connect the handles to the shoulder arch by sliding the smaller end of the handle assembly through the stainless steel cylinder. Secure the two sections together by inserting the tilt lever (6) through the stainless steel cylinder and threading it into the handle section. The tilt lever adjusts the tension on the tilt action of the handles. The position of the lever can be adjusted without loosening – simply grab the lever and press on the red button, then adjust the angle of the lever.



- 2) The swiveling counterweight can be adjusted to the left or right to compensate for balance issues created by the camera and other mounted accessories. For now, tighten the pivot knob thoroughly so it doesn't move while you are mounting the camera and accessories and making adjustments to the Rig.



- 3) Attach the quick-release plate to your camera using the appropriate screw. Remove the unused screw and store in a secure location. Once the quick-release plate is firmly attached to your camera, set it aside.
- 4) Attach the belt to your waist with the holster facing front. Take the spring pod and insert the flat end into the holster, making sure to run the pod through the D-ring at the top of the holster. **Do not loosen the spring pod clamps yet.**

- 5) Make sure the tilt lever on the DV Media Rig is tightened so the handles don't rotate easily and the unit can stand securely. Take the camera with quick-release plate attached and secure it to the base plate on the DV Media Rig. Pick up the Rig and place it over your shoulder. The front of the Rig must be attached to the spring pod. Insert the brass tip of the spring pod into the coiled spring on the underside of the handle assembly. Once the spring pod is secured, loosen the spring pod clamps.



- 6) If you plan to attach any accessories such as a light, mic, XLR mic adapter, etc., go ahead and attach them to the accessory mount and fix it to the Rig.
- 7) With the Rig fully mounted and loaded, you'll know if any position and balancing adjustments need to be made. You can adjust the side-to-side balance of the camera by loosening the single-wing knob above the spring pod attachment point and sliding the camera platform. You can also adjust the side-to-side balance by pivoting the counterweight at the rear.
- 8) The primary positional adjustment is at the shoulder pivot. This will allow you to change the angle and height of the shoulder arch for maximum comfort.



The tilt lever allows you to change the amount of tension in the tilting mechanism or soft-lock the tilt position. Never operate the Rig with the tilt lever excessively loose.

Depending on the weight of your camera, you may want to lock one of the sections of the spring pod to minimize the spring action. You can also extend and lock both sections for elevated shots.

The DV Media Rig is covered by a 2-year parts & labor warranty against defects. If you have any questions, give us a call or shoot us an email – www.varizoom.com